

Outline

This is a vacuum pump that evacuates by the reciprocating motion of a rubber thin film (diaphragm). Simple structure and easy handling. DA series is a standard type.

Features and Cautions on use

• Diaphragm type pump creates vacuum by reciprocate movement of rubber diaphragms. Pump structure makes Oil-free environment and maintenance easy. Various pumping speed and two/single stages are selectable depends on your required pressure and pumping volume.

Specification

Item	Unit	50Hz	60Hz	
Actual Pumping Speed	L/min	100	110	
Ultimate Pressure	Pa	13.3	13.3×10 ³	
Olimate Pressure	kPa	-88	-88 #1	
Motor Output	W	20	200	
Weight	kg	11		
Inlet, Outlet port diameter	mm	O.D. \$\$\phi\$ 12\times I.D. \$\$\$ (Rc 1/4)		
Ambient temperature	Ĵ	7~	7~40	
Overall dimensions	mm	150(W) × 232	2(L) × 305(H)	
RoHS applied				


^{#1}: Gauge pressure

Power Supply/Voltage


Voltage	Certificate	Remarks
Single phase, 100V	_	
Single phase, 200-220V	_	
Three phase, 200-220V	CE, TUV, cTUVus	DAT-100SA
at Constraint A. Istada and the constraint states to a sound the sound	de Elemente en este elemente de la consecuent la com	the same set and a list of the same set.

TUV Certification: A high-quality product that complies with European standards as assessed by an international third party that conducts product safety testing and certification.

Outline Drawing



Pumping Speed Curves



Remarks

- The pump is stopped when the lord is operated, and the pump can't be operated just after that. In this case, please return the atmospheric pressure the inside of the pump.
- The pump will not often operate normally if it is used with corrosive gases, organic solvents, liquids, or condensed gases (eg steam). The pump will not often operate normally if it is used with gases containing particles or dust etc.
- It is a pump only in the room. Please do not set it up in the place, that rain and water splash, and outdoors.
- It may cause the failure of the pump if it is used for long hours
- close to the atomospheric pressure.

Applied optional part items

No.	Category name	Series	Name
1	Maintenance Kit	Maintenance Kit Series	Maintenace Kit for DAT-100S
2	Anti-vibration Rubber	Anti-vibration Rubber	Anti-vibration rubber (ME-15)
3	Anti-vibration Rubber	Anti-vibration Rubber	Anti-vibration rubber (ME-20)
4	Anti-vibration Rubber	Anti-vibration Rubber	Anti-vibration rubber (ME-25)

〒881-0037 宮崎県西都市大字茶臼原291-7 TEL:(0983)42-1411(代) FAX:(0983)42-1422	アルバック機工株式会社
	宮崎県西都市大字茶臼原291-7
	TEL:(0983)42-1411(代) FAX:(0983)42-1422